



OPERATING MODE

Panify has one single operating mode that take 5 DMX channels.

DMX PROTOCOL

<i>DMX Parameter</i>	<i>FUNCTION</i>
1	PAN
2	PAN FINE
3	CONTINUOUS PAN
4	PAN DIRECTION
5	FUNCTION

FUNCTIONS DETAILS

<i>DMX Parameter</i>	<i>Bit Values</i>	<i>Function</i>
1		PAN
	000 – 255	Pan positioning
2		PAN FINE
	000 – 255	Fine Pan positioning
3		CONTINUOUS PAN
	000 – 002	Unused range
	003 – 255	Pan rotation from Slow to Fast
4		PAN DIRECTION
	000 – 125	CW
	126 – 129	STOP
	130 – 255	CCW
5		FUNCTION
	000 – 011	Unused range
	012 – 037	Dummy
	038 – 042	Display ON (Default)
	043 – 047	Display OFF
	048 – 052	Pan Reset
	053 – 057	Pan speed Normal
	058 – 062	Pan speed Fast (Default setting)
	063 – 067	Pan speed Boost
	068 – 255	Unused range
		IMPORTANT: The functions are activated/selected staying in the necessary range for 5 seconds