



EW-DX Frequency range Y1-3

1785.200 - 1799.800 MHz

Standard mode - 600 kHz frequency spacing

SENNHEISER

Channel	Frequency
1	1785.200
2	1785.800
3	1786.400
4	1787.000
5	1787.600
6	1788.200
7	1788.800
8	1789.400
9	1790.000
10	1790.600
11	1791.200
12	1791.800
13	1792.400
14	1793.000
15	1793.600
16	1794.200
17	1794.800
18	1795.400
19	1796.000
20	1796.600

Channel	Frequency
21	1797.200
22	1797.800
23	1798.400
24	1799.000
25	1799.600

Channel	Frequency

Channel	Frequency

Channel	Frequency



Please contact your radio licensing authority in your country, who will advise you on the available frequencies and transmitter power requirements.
For further details see www.sennheiser.com/sifa
Informieren Sie sich bei Ihrer zuständigen Zulassungsbehörde über die erlaubten Sendefrequenzen und Sendeleistungen.
Weitere Infos finden Sie unter www.sennheiser.com/sifa