
ETC Setup Guide





Corporate Headquarters Middleton, WI, USA +1 608 831 4116 London, UK +44 (0)20 8896 1000 Holzkirchen, DE +49 (80 24) 47 00-0 Rome, IT +39 (06) 32 111 683 Hong Kong +852 2799 1220 Paris, FR +33 1 4243 3535 Web etcconnect.com Support support.etcconnect.com Contact etcconnect.com/contactETC © 2023 Electronic Theatre Controls, Inc. Trademark and patent info: etcconnect.com/ip Product information and specifications subject to change. ETC intends this document to be provided in its entirety.

Product information and specifications subject to change. ETC intends this document to be provided in its entirety. 4267M2290 Rev C Released 2023-01

Response Opto-Splitter How to...

...mount to DIN rail

Ensure DIN rail is securely mounted


Hook top of unit over the upper DIN rail edge (1)

Depress until bottom clip on unit seats completely (2)

To remove, use a small screwdriver to release the orange retaining clips on top and bottom of the unit


...wire DIN rail power

Wire the 3 position terminal connector with positive, negative, and ground wires in the appropriate terminals.




- Strip length: 6 mm (1/4 in)
- Wire size: 0.5 4 mm2 (22 - 12 AWG)
- Torque: Max 0.5 Nm (4.4 lb-in)

...mount to equipment rack



...reverse power connector





WARNING: RISK OF ELECTRIC SHOCK! Power must be off when you perform these procedures.

AVERTISSEMENT: RISQUE DE DÉCHARGE ÉLÉCTRIQUE! L'alimentation doit être éteinte avant d'exécuter cette procédure.



WARNING: RISK OF ELECTRIC SHOCK! Rack-Mount units must be connected to a protective earthing conductor.

AVERTISSEMENT: RISQUE DE DÉCHARGE ÉLÉCTRIQUE! Les appareils montés en rack doivent être connectés à conducteur de terre de protection.